



## ELMED Sales & Service News

October 2008

To assist our customers in finding answers to basic questions, ELMED introduces the **Sales & Service News**. Here you can find answers to commonly asked questions about customer service, product and corporate information. In addition to our Sales & Service News, the ELMED websites also provide detailed information on available brochures and data sheets.

### Did you know ?

#### Q: How to change the operating mode of the ISOTEST 4S safety switch ?

**A:** Switch the ISOTEST 4S on. Turn the rotary switch "Filter" to the position with the symbol for the desired operating mode of the safety button. The blue LED adjacent to the symbol for indicating the actual operating mode flashes.



Press and hold the safety button at the handle. After one short and one long hooter alarm, the new operating mode is enabled.



Now, the blue LED adjacent to the corresponding symbol for the newly selected operating mode flashes. Release the safety button and turn rotary switch "Filter" to its position "Standard". The blue LED adjacent to the symbol for the selected operating mode is lit. The test equipment is now ready for use.



**Important:** For testing operation make sure that the rotary switch is set to the position „Standard“ or the chosen „Filter“ setting.